
TERMINAL BLOCK X4/10
FROM TERMINAL BLOCK (DIAGRAM 1 OF 2)
FROM IGNITION/STARTER SWITCH (DIAGRAM 1 OF 2)
EXTERIOR LAMP SWITCH
FOG LAMP SWITCH
PARK
HEAD
OFF
RH
LH
STANDING
STARTER
ALTERNATOR
WARNING BUZZER, EXTERIOR LAMP FAILURE MONITORING UNIT
DAYTIME RUNNING LAMPS (CANADA)
FROM FUSE 15 (DIAGRAM 1 OF 2)
COMBINATION SWITCH
FLASH -TO- PASS
HI
LO
FUSE BOX
FUSE 26 10A
FUSE 10 7.5A
FUSE 9 7.5A
FUSE 7 10A
FUSE 8 7.5A
FUSE 11 7.5A
FUSE 12 7.5A
FUSE 13 7.5A
FUSE 14 7.5A
FRONT FOG LAMPS
REAR FOG LAMPS
ATA CONTROL UNIT
HEADLAMP CLEANING SYSTEM
LEFT STANDING LAMP, LEFT TAILLAMP, LEFT SIDE-MARKER LAMPS
LEFT LOW BEAM HEADLAMP
RIGHT LOW BEAM HEADLAMP
LEFT HIGH BEAM HEADLAMP, HIGH BEAM INDICATOR
RIGHT HIGH BEAM HEADLAMP
DAYTIME RUNNING LAMPS (CANADA)
RIGHT STANDING LAMP, RIGHT TAILLAMP, RIGHT SIDE MARKER LAMPS, LICENSE PLATE ILLUMINATION, ENGINE SPEED INCREASE DIODE MATRIX
FROM IGNITION/ STARTER SWITCH (DIAGRAM 1 OF 2)
ENGINE CONTROLS
BASE MODULE
IGNITION COIL
INSTRUMENT CLUSTER
(BRIDGE)
FUSE 19 7.5A
FUSE 20 10A
FUSE 21 15A
FUSE 23 7.5A
FUSE 24 7.5A
FUSE 25 15A
(NOT USED)
AUTOMATIC CLIMATE CONTROL, A/C COMPRESSOR, BASE MODULE KICKDOWN SWITCH
HEATED WINDSHIELD WASHER NOZZLES, POWER/HEATED MIRRORS, TRANSMISSION OIL COOLER
INJECTORS, INSTRUMENT CLUSTER, CRUISE CONTROL SWITCH, GLOW/STARTER SWITCH, STOP LAMP SWITCH, CENTER HIGH MOUNTED STOP LAMP
BASE MODULE, PURGE CONTROL VALVE, INSTRUMENT CLUSTER, EXTERIOR LAMP FAILURE MONITORING MODULE, INTERIOR LIGHTS, ELECTROMAGNETIC AIR INJECTION PUMP CLUTCH, STOP LAMP SWITCH, SEAT BELT WARNING MODULE, DAYTIME RUNNING LIGHTS, ENGINE CONTROLS
TURN SIGNAL/HAZARD WARNING FLASHER RELAY, FAN RELAY MODULE, STARTER LOCK-OUT/ BACKUP LAMP SWITCH, SHIFT VALVE/SOLENOID VALVE
FROM TERMINAL BLOCK X4/10 (DIAGRAM 1 OF 2)
CONVENIENCE RELAY
FROM MAXI-FUSE BOX (DIAGRAM 1 OF 2)
FUSE 36 10A
FUSE 33 20A
FUSE 27 25A
FUSE 28 7.5A
FUSE 29 20A
FUSE 37 30A
FUSE 38 30A
FUSE 30 20A
FUSE 31 30A
FUSE 32 30A
FUSE 40 30A
FUSE 41 30A
FUSE 17 20A
FUSE 18 15A
ELECTRONIC ANTENNA
FRONT HEATED SEATS
LEFT FRONT POWER SEAT
LEFT/RIGHT SEAT MEMORY, DRIVER MEMORY STEERING COLUMN ADJUST
REAR POWER BENCH SEAT W/ PASSENGER SEAT ADJUSTMENT OR LEFT REAR POWER SEAT W/ FRONT PASSENGER SEAT ADJUSTMENT
REAR POWER SEAT, TRUNK LAMP, RIGHT REAR HEAD RESTRAINT
RIGHT FRONT POWER SEAT
AIR CONDITIONING, AUXILIARY COOLANT PUMP CONTROL RELAY MODULE
IGNITION SHUT-OFF RELAY, RADIO, STEERING ANGLE SENSOR, GENERIC SCAN TOOL CONNECTOR, INSTRUMENT CLUSTER, MAKE-UP MIRROR ILLUMINATION, TURN SIGNAL/ HAZARD FLASHER SWITCH
85062