
FROM TERMINAL BLOCK (DIAGRAM 1 OF 2)
TERMINAL BLOCK X4/10
FROM IGNITION/STARTER SWITCH (DIAGRAM 1 OF 2)
EXTERIOR LAMP SWITCH
FOG LAMP SWITCH
PARK
OFF
RH
STANDING
LH
HEAD
STARTER
ALTERNATOR
WARNING BUZZER, EXTERIOR LAMP FAILURE MONITORING UNIT
DAYTIME RUNNING LAMPS (CANADA)
FROM FUSE 15 (DIAGRAM 1 OF 2)
COMBINATION SWITCH
LO
HI
FLASH -TO- PASS
FUSE BOX
FUSE 26 10A
FUSE 10 7.5A
FUSE 9 7.5A
FUSE 7 10A
FUSE 8 7.5A
FUSE 11 7.5A
FUSE 12 7.5A
FUSE 13 7.5A
FUSE 14 7.5A
EXTERIOR LAMP FAILURE MONITORING MODULE
ATA CONTROL UNIT
HEADLAMP CLEANING SYSTEM
DAYTIME RUNNING LAMPS (CANADA)
FROM IGNITION/ STARTER SWITCH (DIAGRAM 1 OF 2)
ENGINE CONTROLS
BASE MODULE
IGNITION COIL
INSTRUMENT CLUSTER
(BRIDGE)
FUSE 19 7.5A
FUSE 20 10A
FUSE 21 15A
FUSE 23 7.5A
FUSE 24 7.5A
FUSE 25 15A
(NOT USED)
AUTOMATIC CLIMATE CONTROL, A/C SWITCH, EMISSIONS SENSOR, IR DAS CONTROL MODULE
HEATED WINDSHIELD WASHER SYSTEM, POWER/HEATED MIRRORS,
CRUISE CONTROL SWITCH, STOP LAMP SWITCH, AUTO DIMMING INSIDE REAR VIEW MIRROR
PURGE CONTROL VALVE, INSTRUMENT CLUSTER, EXTERIOR LAMP FAILURE MONITORING MODULE, INTERIOR LIGHTS, STOP LAMP SWITCH, SEAT BELT WARNING MODULE
TRANSMISSION RANGE SWITCH HORN RELAY MODULE STARTER LOCK-OUT/ BACKUP LAMP SWITCH,
FROM TERMINAL BLOCK X4/10 (DIAGRAM 1 OF 2)
CONVENIENCE RELAY
FROM MAXI-FUSE BOX (DIAGRAM 1 OF 2)
FUSE 36 10A
FUSE 33
FUSE 27
FUSE 28 7.5A
FUSE 29 20A
FUSE 37 30A
FUSE 38 30A
FUSE 30 20A
FUSE 31 30A
FUSE 32 30A
FUSE 40 30A
FUSE 41 30A
FUSE 17 20A
FUSE 18 15A
(NOT USED)
ELECTRONIC ANTENNA
FRONT HEATED SEATS
LEFT FRONT ESA MODULE
REAR POWER BENCH SEAT W/ PASSENGER SEAT ADJUSTMENT OR LEFT REAR POWER SEAT W/ FRONT PASSENGER SEAT ADJUSTMENT
LEFT/RIGHT SEAT MEMORY, FRONT ESA MODULES
REAR POWER SEAT
RIGHT FRONT ESA MODULE
AIR CONDITIONING, IR DAS CONTROL MODULE
STEERING ANGLE SENSOR, GENERIC SCAN TOOL CONNECTOR, DOME LAMP, COMBINATION RELAY
107037